

# Pipework Cleaner

## For cleaning the pipework

### Application

Over a period of time pipework can become contaminated. The impurities in the pipework absorb the disinfectant, causing problems with the water treatment. Pipework Cleaner consists of special granules for deep cleansing of the spa pipework.

### Dosing recommendations

Use 200 g/m<sup>3</sup> for cleaning the spa before changing the water.

Add 200 g per m<sup>3</sup> of Pipework Cleaner to the filter cartridge or dosing device and let the pump run for approximately 5 minutes. Should dosing in the filter cartridge or skimmer not be possible, dissolve the granules in a bucket with approximately 5 L water and dose directly into the spa with the pump running. Allow the granules to soak for approximately 1 hour and again briefly circulate. Then drain the spa and rinse with clean water. Do not use the spa during this treatment. If necessary, clean the spa with SpaTime Surface Cleaner and then fill with fresh water.



Article number 5512201 | 1 kg